

Contact Us:

Ireland: 086 8133 228 NI: 07718 760 273 sales@svstv.com



GPS Safety Tracking SystemCompetitor Information



SOS Button:

If you or someone else needs immediate medical services / ambulance / rescue, then flip up the red safety cover and turn on the SOS Button.

Please do not use this button for anything other than to seek emergency services to your location. Call the emergency number to give details.

This will cancel the stage and send services to the location. All remaining cars waiting at the start line will be sent via alternative road book.

OK Button:

If you have to make an unscheduled stop during a live stage, perhaps a puncture or car has broken down etc, and you do not need emergency services, then please always remember to press the OK Button for at least a 2 second press. This tells the control room that you are OK and do not need any help at this time unless another button is pressed to escalate the situation further.

Road Blocked Button:

If you come across a blockage, or are unfortunate to cause a blockage, then press the road blocked button. This button stays on until the stage is clear again. An active alarm means stage is still blocked. Turning the switch off again means the stage is now clear. Call the emergency number / control room to give details. This tells the control room that they need to hold the start line and try to warn the cars still live on the stage of the blockage ahead. The stage must be cleared within 10mins and your help to clear the blockage and then leave the stage as quickly as possible, will mean the stage may be re-started.

Fire Button:

As the name suggests, this button should only be activated when there is a fire. It may be your car, or another car, or perhaps something else that needs help putting the fire out. It should be kept active and not turned off until the fire has been dealt with. Call the emergency number to give details.

This tells the control room to stop the stage and send services to your location to help with the fire. When the switch has been turned off, it tells us that the fire is under control.

Red Flags:

If you receive a 'Red Flag' warning through the tracking equipment, the two red led lights will turn on and the alarm siren will sound very loudly. This means that you immediately slow down and press the 'OK Button' to acknowledge the warning from the control room, and it will also silence the alarm.

Please remember that everything is about communication with the control room and back to the competitors.