



## PASSWORD PRL

**942627**

Press the WHITE button to enter the menu. Press MANAGE in Roadbook and choose **PRL**. Click on ALL DATA (red) Enter the password Click on the green tick, 2 times.